

Installation Instructions



WoodWorks and Woodworks FR Vector (Backing Tile)

1. Please ensure that WoodWorks Vector Tiles are face down on a table with a protective cover.
2. Check to make sure the safety clips have been installed correctly as instructed in the WoodWorks Vector Assembly and Installation Instructions Guide.
3. Place the Pre-cut Optra Backing Tile (564mm x 564mm) on the back of the WoodWorks Vector **Face Down**.
4. Measure **15mm** from the Face edge of the WoodWorks Vector tile (594mm x 594mm) to position the Optra Backing Tile (564mm x 564mm).

The following steps specify the screw fixing of the Optra Panel to the back of the WoodWorks Vector Panel.

5. Once the Optra Panel is in the correct position measure **100mm** in from the WoodWorks Vector edge with no Vector Safety Clip (as per attached drawing) and **30mm** in from the WoodWorks Vector edge with the Vector Safety Clip (as per attached drawing).

6. Once the correct fixing points are found on the Optra Backing Tile (564mm x 564mm) use a #8 x 20mm Button Head 'S' Point Screw to secure the Backing tile to the WoodWorks Vector.
7. **IMPORTANT – Ensure that the #8 x 20mm Button Head 'S' Point Screw is not over screwed into the mineral fibre backing Tile as this may penetrate the face of the WoodWorks Vector Tile.**
8. Please repeat the process and ensure that the 2 corners of the Optra Backing Tile are screw Fixed.

Note – While reading this guide ensure you have a copy of the Backing Tile Installation Drawing. If you do not have this drawing as a reference please do not install the Backing Tile until you obtain a copy from Your Armstrong Ceilings Representative.

MORE INFORMATION

For complete technical information, detail drawings, CAD design assistance, installation information and many other technical services, call your local Armstrong Ceilings representative.

For the latest product selection and specification data, visit armstrongceilings.com.au

Contact us

NSW/ACT

Armstrong Ceiling Solutions (Australia) Pty. Ltd.
75 Long Street, Smithfield, NSW, 2164
Telephone (02) 9748 1588

VIC/TAS

Armstrong Ceiling Solutions (Australia) Pty. Ltd.
Factory 5, Soccio Place, 205-233 Abbots Road,
Dandenong South, VIC 3175
Telephone (03) 8706 4000

QLD / NT

Armstrong Ceiling Solutions (Australia) Pty. Ltd.
18-24 Beal Street, Meadowbrook, QLD 4131
Telephone (07) 3809 5565

SA

Total Building Systems Pty. Ltd.
160 Grand Junction Road, Blair Athol, SA 5084
Telephone (08) 7325 7555

WA

Ceiling Manufacturers of Australia Pty. Ltd.
3 Irvine Street, Bayswater, WA 6053
Telephone (08) 9271 0777

New Zealand

Comfortech Building Systems Ltd.
27B Smales Road, East Tamaki, Auckland 2013
Telephone 64-9-276 4000

